

Guide des tailles – Chaussures Dynafit

Chaussures Homme Dynafit

	39	39.5	40	40.5	41	41.5	42	42.5	43	43.5	44	44.5	45	45.5	46	46.5	47	47.5	48	48.5	49
	6	6.5	7	7.5	8	8.5	9	9.5	10	10.5	11	11.5	12	12.5	13	13.5	14				
(cm)	25	25.5	26	26.5	27	27.5	28	28.5	29	29.5	30	30.5	31	31.5	32	32.5	33				

Chaussures Femme Dynafit

EU	35	35.5	36	36.5	37	37.5	38	38.5	39	39.5	40	40.5	41	41.5	42	42.5	43
UK	3	3.5	4	4.5	5	5.5	6	6.5	7	7.5	8	8.5	9				
US																	
Longueur (cm)	22	22.5	23	23.5	24	24.5	25	25.5	26	26.5	27	27.5	28				

Chaussures de Ski Dynafit

2.5	23	23.5	24	24.5	25	25.5	26	26.5	27	27.5	28	28.5	29	29.5	30	30.5
35 2/3	37 1/3	38	38 2/3	39 1/3	40	40 2/3	41 1/3	42	42 2/3	43 1/3	44	44 2/3	45 1/3	46	46 2/3	47 1/3
5	5.5	6	6.5	7	7.5	8	8.5	9	9.5	10	10.5	11	11.5	12	12.5	13
6	6.5	7	7.5	8	8.5	9	9.5	10	10.5	11	11.5	12	12.5	13	13.5	14

Casques Dynafit

Taille	XS	XS-S	S	M	M-L	L	XL	XL-XXL	XXL
Tour de tête (cm)	53-58		53-58		58-62				